


Table of Contents

	Page
Part 1 : Getting Started with the Application.....	1
1.1 Creat an Account.....	2
1.2 Confirm Email Address.....	3
1.3 Sign In.....	3
1.4 Forgot Password.....	4
Part 2 : Application Usage: Home Page.....	5
Part 3 : Application Usage: Devices Page.....	6
3.1 Device Search.....	6
3.2 Setting Device Location.....	7
3.2.1 Add Location.....	7
3.2.2 Edit Location.....	7
3.2.3 Delete Location.....	8
3.3 Details of device cards.....	9
Part 4 : Device Control Page (Dashboard).....	10
4.1 Preset for the automatic device testing schedule.....	11
Part 5 : Profile.....	12
Part 6 : More.....	13
6.1 Settings.....	14
6.2 Delete Account.....	15
Part 7 : Synchronization.....	16
7.1 Real-time Synchronization.....	16
7.2 Synchronize the testing schedule.....	17
7.3 Synchronize device status.....	17
Part 8 : Automatic device testing operation function.....	18
8.1 Add automated testing feature.....	18
8.2 Save testing schedule Preset.....	19
8.3 Edit the automated testing.....	20
8.4 Event.....	21
Part 9 : Factory Reset.....	22


1. Getting Started with the Application




Recommendations for users

- Please update your operating system to iOS 9.0 or higher for Apple devices, or Android version 6.0 or higher for Android devices. If your current version is lower than these requirements, the application may not function properly.
- To use the application, users must enable usage on their mobile devices as follows:
 1. Internet Connection
 2. Bluetooth Connection
 3. Location Services


1.1 Creat an Account




Tap on the 'Create One' button.




1. Enter your username, email address, and password.
2. Select to agree to the Terms & Conditions and Privacy policy
3. Select to agree to the Terms & Conditions. Tell me about new product, special offers promotions via the email.
4. Tap on the 'Create account' button.



Tap on the 'Next' button.




1. Select the user's country.
2. Tap on the 'Next' button.



Tap on the 'Sign In' button.

1.2 Confirm Email Address



Select the Sunny Link email
– Confirm your email address.




Tap on the 'CONFIRM EMAIL' button.



Confirm Email Address

1.3 Sign In




1. Enter your name, email account, and password.

2. Select 'Remember me' (if you want to automatically sign in next time).

3. Tap on the 'Sign In' button.


1.4 Forgot Password

1




Tap on the 'Forgot password ?' button.

2



1. Enter your email.
2. Tap on the 'Send' button.

3



Select the Sunny Link Reset Password email.

4



Tap on the 'RESET PASSWORD' button.

5




1. Enter a new password for accessing the account and enter the password again for confirmation.
2. Tap on the 'RESET PASSWORD' button.

6



The password change has been successful.

2. Application Usage: Home Page




3. Application Usage: Devices Page


3.1 Device Search




Tap on the 'Devices' icon.



Tap on the 'SCAN' button.




Nearby devices will be displayed.



Tap on the button.




Enter the information of the device you want to display.




Filtering device cards based on matching information

3.2 Setting Device Location


3.2.1 Add Location



Tap on the 'Devices' icon.




To add a new location, tap on the icon.




1. Enter the name of the location and a description of the location.
2. Tap on the 'Save' button.

3.2.2 Edit Location




Editing location information by tapping on the icon.




1. Enter the name of the location or a description of the place.
2. Tap on the 'Save' button.


3.2.3 Delete Location



Deleting a location by tapping on the icon.




Select to confirm the desire to delete.




The place that is currently in use at that time will not be allowed to be deleted.


3.3 Details of device cards.




4. Device Control Page (Dashboard)



4.1 Preset configuration for automatic device testing schedule




1. Ensure the device is successful connected.
2. Tap on the icon.




1. Tap to select the preset you want to use or clear all automatic testing schedules.
2. Tap on the icon to view details of each item.

5. Profile



Managing General Information


1. Username
2. Email Address (not editable)
3. Password
4. Country




Managing Company Information

1. Company Name
2. Contact Person
3. Company Address
4. Phone Number
5. Email Address


6. More




6.1 Settings





Settings that users can customize



Select language preference within the app in both English and Thai.




Display information about various events of the device




1. Users can set the desired time intervals
2. Specifying the duration for manually testing a device's lamp using the TEST button on the device card


6.2 Delete Account




Tap on the 'Delete Account' button.




Tap on the 'OK' button.



1. Enter the email account.
2. Tap on the 'OK' button.




1. Enter the account password.
2. Tap on the 'OK' button.



After account deletion is completed, it will return to the Sign in page


7. Synchronize

7.1 Real-time Synchronization



Automatic synchronization upon entering the Dashboard page, which typically takes approximately 4 seconds.

7.2 Synchronize the testing schedule




Tap on the "Testing Schedule" icon

The syncing process takes 4 seconds

1. Display the date and time of the last synchronization.
2. Display the date of the last testing schedule synchronization.
3. Display the testing card (if there is a scheduled test).

7.3 Synchronize device status.




Tap on the "Testing Overall Testing Results" icon.

The syncing process takes 35 seconds.

1. Display the date and time of the last synchronization.
2. Display the date of the last device status synchronization.
3. Display the number of tests conducted and power failures.

8. Automated device testing functionality.

8.1 Add automated testing feature.




1. Ensure the device is successful connected.
2. Tap on the icon.


Tap on the "+" icon.

1. Set up advance settings for automated testing
2. Tap on the 'Save' button.


8.2 Save the testing schedule preset.




1. Ensure the device is successful connected.
2. Tap on the icon.



- Tap on the 'Save' button.



1. Specify the name of the preset.
2. Tap on the 'OK' button.




1. The preset has been saved.
2. Tap on the icon to delete the unwanted preset from the list.

8.3 Edit the automated testing.

You can edit the automated testing in two ways, as follows:


1



Tap the device's card on the date that you want to edit.


Tap on the icon to navigate to the calendar.

2




1. Edit the advance settings for automated testing.
2. Tap on the 'Save' button.

2




Tap on the date with the scheduled test you want to edit.

3






1. Tap to delete the testing schedule.
2. Tap to navigate to the page for editing automated testing schedules.

4



1. Edit the advance settings for automated testing.
2. Tap on the 'Save' button.

8.4 Event




1. The circle symbols of different colors signify the following events:
 Orange : Power outage occurred
 Green : Automated or manual testing is in progress
 Red : Automated testing schedule is set
2. The symbols will be indicated below the date numbers.

Tap on the "=" icon or tap on the date with a circle symbol to navigate to the Events page.


Events or occurrences that happen each day.

9. Factory Reset

1




or



Tap on the successful connection icon.

Tap on the successful connection icon.

2



Tap on the "Yes" option.

3



Display a message asking the user to enter the OTP (One-Time Password), with the system sending the code to the user's Sunny Link email account.



If you select the email from Sunny Link, you will find the OTP code.




1. Enter the OTP code.
2. Tap on the 'OK' button.



 The sound signal will be a long beep for 2 seconds, repeated twice.

The LED at the 60-minute position will shine accompanied by a long beep for 2 seconds, repeated twice. Afterward, all LEDs on the indicator will turn off for 1 second.



The device will automatically restart. The app screen will display a message indicating that the reset was successful.


Contact us

ISON IMPORT-EXPORT CO., LTD.

Head Office 2915-2917 Ladprao Road,
Klongjan, Bangkapi, Bangkok 10240

phone 02 378 1034-5

fax 02 370 1672



www.sunnyemergencylight.com